

## Front Panel

### USB slot

USB slot, placed under the lid, allows you to connect external devices.

### Display

Display presents current time or a channel name.

### LEDs


LED indicators inform about the current status of the decoder.

### Function buttons

These buttons perform the same function as the correspondent ones on the remote control.



## Rear Panel



- |  |   |   |
|--|---|---|
| <p>1. CVBS Video and Stereo Audio Output</p> <p>2. CVBS Video and Stereo Audio Output</p> <p>3. S-VIDEO Output</p> | <p>4. Component Output (HD Analog Output)</p> <p>5. HCNA port (to HCNA coax wiring)</p> <p>6. RF modulated output to TV</p> <p>7. Ethernet port</p> | <p>8. S/PDIF (Digital Audio Output)</p> <p>9. HDMI™ (HD Digital Output)</p> <p>10. USB port</p> <p>11. Power plug (12V)</p> |
|--|---|---|

## Accessories

As you unpack your digital decoder, please make sure that the following accessories are included:



Remote control\*  
(\*optional; actual model may vary)



Batteries\*  
(\*optional)



Power Adapter



RCA Component Cable (YPbPr)



RCA AV Cable

## Copyrights

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

HDMI, the HDMI Logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

This product is protected by certain intellectual property rights of Microsoft Corporation. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft or an authorized Microsoft subsidiary.

Content providers are using the digital rights management technology for Windows Media contained in this device ("WM-DRM") to protect the integrity of their content ("Secure Content") so that their intellectual property, including copyright, in such content is not misappropriated. This device uses WM-DRM software to play Secure Content ("WM-DRM Software"). If the security of the WM-DRM Software in this device has been compromised, owners of Secure Content ("Secure Content Owners") may request that Microsoft revoke the WM-DRM Software's right to acquire new licenses to copy, display and/or play Secure Content. Revocation does not alter the WM-DRM Software's ability to play unprotected content. A list of revoked WM-DRM Software is sent to your device whenever you download a license for Secure Content from the Internet or from a PC. Microsoft may, in conjunction with such license, also download revocation lists onto your device on behalf of Secure Content Owners.

Windows Media is a trademark of Microsoft Corporation.

This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Rovi, and is intended for home and other limited viewing uses only unless otherwise authorized by Rovi. Reverse engineering or disassembly is prohibited.

HomePNA logo is registered trademark of the HomePNA Alliance.

ADB, the ADB Logo are registered trademarks of ADVANCED DIGITAL BROADCAST S.A.

All other product or service names are the property of their respective owners.

